



TRIM CRIMP FROM TOP OF FLUE/S



PLACE COVER CONE OVER FLUES AND POP RIVET (OR SCREW) TO OUTER FLUE TO FIX



COWL BASE



PLACE COVER CONE OVER FLUES AND POP RIVET (OR SCREW) TO OUTER FLUE TO FIX



GREASE SPINDLE THEN SECURE COVER CONE TO OUTER FLUE & FIX COVER CONE TO BASE WITH 4 RIVETS/SCREWS



LOOSEN SCREW ON COWL (SPINDLE), PLACE ON PIN THEN TIGHTEN SCREW WHEN LOCATED